

ORIGINALNI TONERI

| Šifra | Oznaka | Koristi se za: | Boja | Kapacitet |
|----------|-------------------|---|------|------------|
| 25803304 | CLT-K504S | CLP-415N/NW, 4195FN/FW | ● | 2.500 str. |
| 25803305 | CLT-C504S | | ● | 1.800 str. |
| 2580331 | MLT-D1082S | ML-1640/2240/2241 | ● | 1.500 str. |
| 2580348 | MLT-D1052L | ML-1910/1915/2525/2540/2545/2580, SCX-4600/4623, SF-650 | ● | 2.500 str. |
| 2580384 | MLT-D116S/ ELS | M-2675, M-2825, M-2875 | ● | 1.200 str. |
| 25803841 | MLT-D116L | SL-M2676N, SL-M2676FH, SL- M2876HN, SL-M2626, SL-M2626D, SL- M2826ND. | ● | 3.000 str. |

SAMSUNG



ORIGINALNI TONERI

| Šifra | Oznaka | Koristi se za: | Boja | Kapacitet |
|---------|---------|--|------|------------|
| 257057 | 505HE | MS310/410/510/610 | ● | 5.000 str. |
| 2570622 | 51B2000 | MX317/417/317/317 | ● | 2.500 str. |
| 2570625 | B232000 | B2338 / B2442 / B2546 / B2650 i uređaji MB2338 / MB2442 / MB2546 / MB2650 | ● | 3.000 str. |

Lexmark



ORIGINALNI TONERI

| Šifra | Oznaka | Koristi se za: | Boja | Kapacitet |
|--------|----------|--|------|------------|
| 254201 | C310 BK | C300/310/330/510/530, MC351/352/361/362/561 | ● | 3.500 str. |
| 254202 | C310 M | | ● | 2.000 str. |
| 254203 | C310 C | | ● | 2.000 str. |
| 254204 | C310 Y | | ● | 2.000 str. |
| 254151 | B432/562 | B432 / 512 / MB562 | ● | 3.000 str. |

OKI



ORIGINALNI TONERI

| Šifra | Oznaka | Koristi se za: | Boja | Kapacitet |
|---------|-----------|---|------|------------|
| 2415861 | KX-FAT472 | KX-MB2177/2170/2137/2130/2120 | ● | 2.000 str. |
| 241500 | KX-FA52E | KX-FC 225/226/228/255/258/265, KX-FP 205/207/215/218/225 | ● | 2 role |
| 241504 | KX-FA57 | KX-FP 343/363/701 | ● | 1 rola |

Panasonic

