

ORIGINALNI TONERI

Canon

Šifra	Oznaka	Koristi se za:	Boja	Kapacitet
241421	C-EXV33	IR-2520/2525/2530	●	14.600 str.
2460347	CRG719H	i-SENSYS LBP 6300/6310/6650/6670/6680, MF 5840/5880/5940/5980	●	6.400 str.
2460356	CRG 728	i-SENSYS Fax-L150/170/410, i-SENSYS MF-4730/4750/4780/4870/4890/4420, MF-4410/4430/4450/4550/4570/4580	●	2.100 str.
2460357	CRG 719	i-SENSYS LBP-5840/5880/6300/6310/6650/6670/6680, MF-5840/5880/5940/5980/6140/6180	●	2.100 str.
2460359	CRG 725	LBP-6000/6020/6030, MF-3010	●	1.600 str.
251285	CRG 718BK		●	3.400 str.
251286	CRG 718C	i-SENSYS LBP-7200/7210/7660/7680, MF-8330/ 8340/8350/8360/8380/8540/8550/8580	●	2.900 str.
251287	CRG 718M		●	2.900 str.
251288	CRG 718Y		●	2.900 str.
251281	CRG-716BK		●	2.300 str.
251282	CRG-716C	i-SENSYS LBP-5050/ i-SENSYS LBP-5050N/ i-SENSYS MF-8030Cn/ i-SENSYS MF-8040Cn/ i-SENSYS MF-8050Cn/ i-SENSYS MF-8080Cw	●	1.500 str.
251283	CRG-716M		●	1.500 str.
251284	CRG-716Y		●	1.500 str.
2460348	CRG 724	i-SENSYS LBP 6750 i i-SENSYS LBP 6780	●	6.000 str
2460353	CRG712 BK	LBP 3010/ LBP 3100.	●	1.500 str.
251415	CRG-046BK		●	2.200 str..
2514151	CRG-046C	I-Sensys LBP653Cdw, LBP654Cx, MF732Cdw, MF734Cdw, MF735Cx	●	2.300 str.r
2514152	CRG-046M		●	2.300 str.r
2514153	CRG-046Y		●	2.300 str.r
24603653	CRG 737 BK	MF211 / MF212 / MF 216n / MF 217w / MF226dn / MF229dw	●	2.400 str

ORIGINALNI TONERI

xerox 

Šifra	Oznaka	Koristi se za:	Boja	Kapacitet
2530183	106R02773	WorkCentre 3025, Phaser 3020	●	1.500 str.
2530185	106R02782	WorkCentre 3215/3225, Phaser 3052/3052NI/3260	●	2 x 3.000 str.
2530675	106R03887	C505	●	12.100 str.
2530711	006R04387 BK		●	1.500 str.
2530712	006R04388 C	Xerox C230/C235	●	1.500 str.
2530713	006R04389 M		●	1.500 str.
2530714	006R04390 Y		●	1.500 str.

